

SingularXYZ



SingularPad
Surveying Software
User Guide

V1.02, modified on 2022.04.01

SingularPad User Guide

Proprietary Notice

Information in this document is subject to change without notice and does not represent a commitment on the part of SingularXYZ Intelligent Technology Ltd. The software described in this document is furnished under a license agreement or non-disclosure agreement. The software may be used or copied only in accordance with the terms of the agreement. It is against the law to copy the software on any medium except as specifically allowed in the license or non-disclosure agreement.

No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose without the express written permission of a duly authorized representative of SingularXYZ Intelligent Technology Ltd.

Corporate Office

SingularXYZ Intelligent Technology Ltd.

Address: Floor 2, Building A, No. 599 Gaojing Road, 201702 Shanghai, China Tel: +86-21-60835489

Fax: +86-21-60835497

Website: <https://www.singularxyz.com> E-mail:

singularxyz@singularxyz.com

Technical Assistant

If you have any questions that can't be solved in this manual, please contact your local SingularXYZ distribution partner. Alternatively, request technical support from SingularXYZ Intelligent Technology Ltd.

Support Email: support@singularxyz.com Support

Skype: [Support.SingularXYZ](https://www.skype.com/join/Support.SingularXYZ)

Your feedback on this manual will help us improve it with future revisions.

©2021 SingularXYZ Intelligent Technology Ltd. All rights reserved

CONTENTS

1 Introduction	1
1.1 Installation environments	1
2 User Interface	1
2.1 Project interface	3
2.2 Device interface	3
2.3 Survey Interface	3
2.4 Tool Interface	4
2.5 Floating window.....	6
3 RTK Workflow.....	7
3.1 Create a new project.....	7
3.2 Connect to receiver	10
3.3 Quick Setup your receiver.....	12
3.3.1 Start your receiver as Base.....	12
3.3.2 Start your receiver as Rover	14
4 RTK Survey-field Data collect	16
4.1 Point survey	16
4.2 Detail survey	20
4.3 Control point survey.....	21
4.4 Point stakeout.....	21
4.5 Line stakeout.....	24
4.6 CAD mapping and stakeout.....	26
4.7 DSM stakeout	32
4.8 Stakeout road	33
4.8.1 Broken station	34
4.8.2 Centerline	35
4.8.3 Vertical Profile.....	43
4.8.4 Standard cross section	44
4.8.6 Slope data	46
4.9 Road stakeout.....	47
4.10 Points database	50
4.11 Data export/import.....	52
4.11.1 Import points data.....	52
4.11.2 Export points data	55
5 Total Station	57
5.1 Connect to total station	57
5.2 Set station	58
5.2.1 Set station & orientation.....	58
5.2.2 Free set station.....	58
5.3 Total station survey	59
5.3.1 Point survey	59
5.3.2 Tps survey.....	61
5.3.3 Point stakeout.....	61
5.3.4 CAD mapping	64
5.3.5 CAD stakeout.....	67
5.3.6 Line stakeout.....	69
5.3.7 DSM stakeout.....	71

SingularPad User Guide

6 Frequently asked functions	73
6.1 Device information.....	73
6.2 Location	74
6.3 Calibrate point.....	76
6.4 Code library manager.....	77
7 About Software.....	79

1 Introduction

SingularPad is professional Android-based surveying software developed by SingularXYZ Intelligent Technology Ltd. SingularPad is fully functional as a field surveying software, equipped with complete work modes and necessary functions for surveyors. Projection/datum configuration, GSM/radio/PDA CORS work modes, point survey/stake out/CAD sketch/COGO calculation and etc. can all be found in SingularPad.

1.1 Installation environments

SingularPad is available, you can connect us to download


<https://www.singularxyz.com>

SingularPad can only run in Android operating system, and the android device specification should be at least or better than the ones listed below:

- CPU: core 2.1 GHz (currently support ARM cortex only)
- At least 4G RAM
- Android System version: ≥ 4.2
- Screen: 4.5 inches
- Screen resolution: 960*640
- Hardware: Bluetooth/Wi-Fi/GPRS

2 User Interface

SingularPad has user-friendly interfaces, which provide you a convenient and effective surveying experience. SingularPad is designed with more advanced features, such as more import formats, more calculation tools, stake out accuracy analysis, auto-sketching by codes, CAD layer editing
etc.



And users can customize the information display content and measurement function menu according to their own usage scenarios, so that the software can better meet the needs of their own applications.

There are four main interfaces, **Project**, **Device**, **Survey** and **Tools** interface. Each main interface includes different functions.



2.1 Project interface

The interface mainly includes Project Manager, Localization, Calibrate Point, Coordinate system and Import/Export data.

- Project Manager: Build/Open/Delete a project.
- Localization: Transfer the WGS84 coordinates to local grid coordinates.
- Calibrate Point: Once change Base coordinate during one project, need do this.
- Coordinate System: Select and manage the datum.
- Points Database: Points manage; check points measured, key in known points and other function.
- Code Library Manager: Management codes in list.
- Import data: Import points file (including CASS, Local coordinates, Geodetic coordinates, SurvCE RW5,FG RAW, Google Earth file and NETCAD format ,PXY file and Carlson coordinate file).
- Export data: CASS, Local Coordinates and Geodetic coordinates, CAD, SHP, Google Earth file (based on WGS84 or Local) etc. you can also export measurement report and stake point report.

2.2 Device interface

This interface is related to setup the GNSS in RTK mode, and check the receiver information.

- Communication: Connect receiver
- Rover: Setup receiver work as rover
- Base: Setup receiver work as base
- Static: Log raw data
- Inspection accuracy: Get 60 points and inspect their accuracy
- Device Settings: Set the rate of output
- Restart Positioning: Get a new coordinate
- Device Information: Show firmware, hardware, status and so on.

2.3 Survey Interface

This interface contains all survey modes, such as the most used function Point Survey, Point Stakeout and Stake Road function.

- Topo survey: Measure points
- Detail Survey: Show local grid coordinate and Lat, Lon coordinate
- Control Point Survey: Measure control points
- Point Stakeout: Stake out points
- CAD: Import dxf or dwg file; edit layers and choose points/lines to stake out
- Line Stakeout: Stake out lines
- DSM Stakeout: Stake out elevation in an area
- Road stakeout: Edit roads and Stake out them

2.4 Tool Interface


The interface mainly includes Coordinates converter, File sharing, Calculator and COGO function.

- Coordinates Converter: Local coordinate, Geodetic coordinate and spatial coordinates are interchangeable
- Angle Converter: Different angle formats are interchangeable, such as dd (Decimal), dd.mmssss, Radian
- Perimeter and Area: Input some points form a face and calculation its area and perimeter
- Calculator: Just like the calculator in your phone
- File sharing: Share files with share code and QR code
- Coordinate inverse calculation: The known coordinates of points A and B, calculate the plane distance, vector, azimuth, elevation difference, ratio of slope and ratio(1:N)
- Point line calculation: The known coordinates of starting point A, end point B and side point C,P is the drop foot, calculate the start distance(AC),end distance(BC),start vertical distance(AP),end vertical distance(BP),Offset distance(CP),Offset angle(α) and corner angle (β).
- Vector: The latitude and longitude coordinates of the starting point A and the end point B are known, and the distance between the two points can be calculated.
- Two lines angel: The known point O, point A and point B, find the angle α between straight line OA and OB.
- Intersection calculation: The known starting point A and terminal point B of line AB , the known starting point C and terminal point D of line CD, calculate the coordinate of intersection point P

SingularPad User Guide

- Resection: The known coordinates of point A and point B, and the known distances of L1 and L2, calculate another coordinate of point P and the angles of triangle ABP
- Forward intersection: he known coordinates of point A and point B, and the known angles of α and β , calculate another coordinate of point P and the sides' length of triangle ABP
- Coordinate positive calculation: The known coordinates of starting point A and end point B, the known length L of line AP and the angle α between line AB and line AP, calculate the coordinate of point.
- Offset point calculation: The coordinates of known line AB starting point A and terminal B, the station distance L1 and offset distance L2 are known, calculate the coordinate of point P
- Extend point calculation: The coordinates of known line AB starting point A and terminal B, the extend distance L1 is known, calculate the coordinate of point P
- Equal point calculation: The coordinates of known line AB starting point A and terminal B, the line is divided into several segments averagely, calculate each coordinate.

2.5 Floating window



- Status Bar

The icons and their descriptions are as follows:

Icon	Description
	Indicates the receiver battery power
	31: number of the satellites used. 36: number of the satellites tracked;
	Rover internal radio mode
	Rover device internet mode
	Rover phone internet mode


The positioning status and their descriptions are as follows:

Status	Description
NONE	The receiver is searching the satellites.
SINGLE	Single positioning solution.
FLOAT	The whole week ambiguity is not fixed.
FIXED	The whole week ambiguity is fixed, high accuracy.
BASE	The base is setup successfully.

Age:***	The diff delay, * represent the diff delay value
H: ..., V: ...	Horizontal RMS, Vertical RMS

3 RTK Workflow


This figure shows the workflow of your survey through SingularPad.



3.1 Create a new project

Click Project manager, click the New button in the lower left corner of the screen and input project name, set coordinate systems parameters and save the project. In Project Manager interface, you can click previous projects in the Project List to remove or open it.





SingularPad User Guide



If you have added one project, you can click the project name in the main interface to check the current project details, including Project Name, Project Path and Coordinate systems parameters. And you can edit it.


SingularPad User Guide

How to create a user defined datum: If you cannot find datum you want in the list, follow instructions below to add one: select ellipsoid para, projection para, datum para, and input horizon adjustment, vertical adjustment and local offsets based on your request. Save and apply it. Meanwhile you can share the coordinate system with your workmates.





3.2 Connect to receiver

After creating a new project, switch to Device, click Connection. You can connect SingularPad with SingularXYZ Y1 GNSS receivers. Or choose other devices.




There are two connection types: Bluetooth and Demo.



SingularPad User Guide

Bluetooth: After connecting SingularXYZ receiver, you can check some information of receiver (like firmware version) in Device Info. And some functions are only available for specified device. After connected successfully, the floating window will show the positioning status.



Tips: If you failed to connect with receiver through SingularPad, you can just follow prompt info to go into the device Bluetooth setting interface to make sure Bluetooth paired successfully. Sometimes you need forget the device Bluetooth, restart the receiver or software and get pair again.

Demo: Simulate connecting SingularPad. On this model, some functions will not work.

3.3 Quick setup your receiver

In SingularPad, you need only one step to start your receiver: Choose work mode and apply. There are some default work modes, three for Base and three for Rover. Choose one mode; you can check the detailed information. If the default work mode suits for you, you can just click Apply to start your receiver. Usually, you need to add one mode yourself.


3.3.1 Start your receiver as Base

There are three modes you can choose, Device Internet, Internal Radio and External radio.

Internal Radio: This mode uses internal radio to transmit the correction data from Base to Rover. You need to set Base and Rover with same protocol and frequency.

The following steps give an example of internal radio transmission.

- Protocol: Supports Transparent, MAC, South or TRIM450S for Base transmission
- Frequency: select a channel or customize a frequency, the range of frequency is 438.125-447.125MHz
- Power: Supports 0.5W, 1W or 2W




SingularPad User Guide


External Radio: This mode uses external radio to transmit the correction data from Base to Rover. You need set Base and Rover with same protocol and frequency.

The steps to start external radio mode is similar with internal radio mode, but you need select the protocol and frequency on the external radio, not In SingularPad.

- Baud rate: This option is to set the baud rate of lemo port.




Internal GSM: This mode uses GPRS (internet data) to transmit the correction data from Base to Rover. You need insert a SIM card to Base, set the Base to log on server (with static IP address), and the Rover receives the correction data by Ntrip protocol. The following figures show an example of Base configuration with internal GSM transmission.



3.3.2 Start your receiver as Rover

This chapter shows how to start receiver as rover with Internal Radio, Device Internet and Phone Internet mode.

Internal Radio: Select the same protocol and frequency with the Base receiver, and then the receiver status will turn single to be fixed. The following steps show an example of internal radio.



Device Internet/Phone Internet: For Device Internet mode, we need insert a SIM card to receiver, for Phone Internet mode, we need make sure controller can access to Internet. You should input the server IP and Port. In addition, enter User (login name) and Password to get mountpoint.




The protocol supports NTRIP, TCP Client

- NTRIP: This is a common Ntrip protocol; you need to set the username and password.

And Device Internet mode only supports Ntrip protocol.


- TCP: This is used to directly obtain the corrections transmitted by TCP protocol.

SingularPad User Guide



4 RTK Survey-field Data Collect

This section describes the basic survey functions of SingularPad including Point Survey, Detail Survey, CAD and Stakeout. In the first, you have to connect to rover receiver and make it fixed.



4.1 Point survey

In the Survey interface, click Point Survey-> enter point name, code and antenna height,

->click  to start or stop collecting data. Tilt Survey option will appear when receiver supports for tilt survey, it is available for SingularXYZ Y1 GNSS receiver. When the pole tilts within 60°, the built-in sensor based tilt measurement system precisely calculates the actual offset according to angle, which can not only meets the requirement of high precision measurement, but also relieves the users from continually checking whether the pole is plumb.

When using it for the first time, you should follow the interface prompts to initialize the IMU module; it will take you a few seconds. You have been confirmed the antenna information, and it is correct.

If calibration expired or you first use the receiver, tap Calibrate and follow the guidance until


SingularPad User Guide

succeed. During operation, make receiver can search the satellites. The angle should be less than 60° , for more accuracy, angle less than 30° will be better. When the pole tilts within 60° , the built-in sensor based IMU precisely calculates the actual offset, which accuracy can up to 2.5 cm.

If you power off the receiver or reset it, need to initialize again. After open IMU button, you can follow the guidance in interface to complete it. When you click IMU button to initialize, it will prompt you to confirm the pole height, default pole height is 1.8 meters. During operation, make receiver search satellites and get a fixed




Of course, you can get some information from the floating window, like coordinate and base distance.

- Click , it will auto jump map center.
- Click  to show the layers or calibration: google map/open street map/map calibration







- Click  to show the whole points on the interface.
- Click  to check point coordinates, you can add, recover, import, and export the

data. After you choose a point, you can check the details and take notes or photos



SingularPad User Guide


• Click  to set settings, display info and tool bar, in setting interface, you can edit receiver parameter, such as solution limit, HRMS limit, VRMS limit; in display info interface, you can add information to floating window you want below the interface; in tool bar interface, you can add or delete options to point survey interface. You can customize the interface to meet whatever layout needs you might have.



4.2 Detail survey



Show both local coordinate and Latitude/Longitude when measuring.

- Click  to start or stop collecting data
- Click  to check point coordinates; you can add note, info, arrow drawing and photo.
- Click  to set settings, display info and tool bar,



4.3 Control point survey

By measuring the coordinates of the same point several times, an accurate coordinate is obtained.




- Click  to average GPS count, interval, and repeat count.

4.4 Point stakeout


Go into Stake point interface, add or import the point coordinates you need to stakeout, of course you can choose from the button library.

- Click Add to input coordinates.

SingularPad User Guide




- Click button library to choose one



- Click Import to get coordinates with different kinds of files; you can also define a new form.

SingularPad User Guide


Choose a point to stake, SingularPad provides a navigation map when staking points/lines. If you are close to the target point enough, it will alarm you based on the alarm range you set. For Y1 receiver, you can use IMU staking function. In the IMU staking, you can open IMU function, and don't need to keep the receiver vertical to the ground, and the tilt angle supports maximum to 60 degrees.



- There is a direction prompt on the floating window
- Click  to start or stop stake points
- Click  to open or close IMU
- Click  to scale automatically
- Click , jump to last point
- Click , jump to next point
- Click , jump to previous point
- Click  to set stakeout settings, display info and tool bar, you can edit the prompt range and range error

SingularPad User Guide

- Click  to open compass




4.5 Line stakeout


Go into Stake line interface, add or import lines you need to stakeout.

- Click Add to input line parameters, there are two types you can choose


SingularPad User Guide



- Click Import to get coordinates with different kinds of files; you can also define a new format.



Choose a line to stake, set calculation mode and interval.




- Click  , jump to next line
- Click  , jump to previous line
- Click  to add stake



4.6 CAD mapping and stakeout

When using for the first time, the CAD interface has no layers and floating window to display the features you need to stake.

SingularPad User Guide




- Click  to create or import a CAD file, supporting *.dxf, *.dwg format



Input parameters and save it



SingularPad User Guide





Find the file you want to stake and import it. After create or import one, you can scan and edit it in the CAD layer.

- Click  to draw features, there are 12 types and methods you can choose, follow the prompts and draw.

SingularPad User Guide






- Click  to find tools; they can help you to work smoothly. For example, to find the intersection points of neighboring circles.



SingularPad User Guide

In the CAD interface, you can choose a feature you want to stake, it will show up in blue. You can know the details about it, including length, start point, end point and center point. And choose the way to stake.



SingularPad User Guide

- Setting: Set the method of stakeout, offset distance, interval etc.
- Start station: If you set the start station as 5m, then final mileage will plus 5m.
- Offset: If you set the offset 5m, then you will stake the line 5m away from the line you choose. Plus and minus represent different sides of the line.
- Setting out by pile by coordinate: including station number, station distance and segment

(1) Station distance: Stake the line at a specified distance, for example, if the line is 40m, you set the specified distance as 8m. Then you will stake the line at 8m distance every segment

(2) Segment: For example, if you set the line segment as 4, then you will stake the line at 4 segments, every segment length is the same.

(3) Station number: You will stake the line at the station at each interval point You can stake it out according to the direction.


(4) key node: It will stakeout the line with starting point, ending point, midpoint, fold point, etc




4.7 DSM stakeout

You can stake the elevation using the design surface, if you don't open a surface before, then you need to add one by adding, importing coordinates or choosing from the button library.

You can get a preview map after adding points and don't forget save it.



At the content list interface, you can find the surfaces you made, and you can edit, share and stake them.




SingularPad User Guide

If the current position is not within the range of the design surface, it will show “Out of Surface!” if the current position is within the range of the design surface, it will show the fill or excavation value.



4.8 Stakeout road

To stake road alignment, first you need design the road, including the broken station, center line, vertical profile, standard cross section and slop. You can design it by editing or importing.



4.8.1 Broken station

Broken station refers to the phenomenon of discontinuity of pile numbers caused by local changes or section measurement. There are two main situations, one is that the front stake is larger than the back stake, and the other is that the front stake is smaller than the back stake. Classification of broken station has two types:

The first type, the front pile number is greater than the back pile number, for example: $K112+943.305 = K112+900.001$, and there will be duplicate piles. In this case, it is called a long chain. The distance between two long chains is the difference between the two piles, 43.304 meters.

The second type, the front pile is smaller than the back pile, for example: $K115+309.227 = K115+320.001$, there will be a discontinuity in the stake. This situation is called a short chain, and the distance between two short chains is also the difference between the two piles, 10.774 meters.

To sum up in a short sentence, it is: if the pile number is repeated, it is a long chain, and if the pile number is broken, it is a short chain.

SingularPad supports long chain, short chain, and supports multiple broken stations at the


SingularPad User Guide

same time. It is recommended that the user enter the broken station first before entering other parameters to avoid changing the broken station later and affect other parameters. Of course, you can also enter the broken later.

When you enter the broken station, it is entered as real number, for example,

$K1+234.000 = K1+238.000$, the mileage before the broken station, you need to enter 1234, the mileage after broken station, you need to enter 1238;



$K112+943.305 = K112+900.001$, the mileage before the broken station, you need to enter 112943.305, the mileage after broken station, you need to enter 112900.001.



4.8.2 Centerline



SingularPad can use three methods to define an alignment: line element, Intersection and Coordinate element method.

SingularPad User Guide




Intersection method


Intersection method refers to point of intersection, which mainly use point coordinates to define the alignment;



First tap Add to input the parameters of the start point and save it



And input parameters of each station one by one, finally input the end point.





You can view details and get a preview map in the center line interface

Tap Check, you can make s inspection about the coordinates with three methods, stakeout

SingularPad User Guide


by station number, distance or input station and offset. check three or four coordinates of the stations to make sure no wrong data entered.



Line element method



SingularPad User Guide

Line element method is more popular, which use element parameters such as line length, azimuth, Spiral and curve to define the alignment





Firstly, choose line element method and add start station.


Next, enter parameters of the features one by one. Usually, after you finish one feature and tap click, it cycle in order of line spiral curve spiral. You can change according to the actual situation.



the first spiral





the second spiral



Tips: in most cases, the start radius of the first spiral is infinite; end radius is the radius of next curve. The start radius of the first spiral the radius of previous curve, end radius is infinite.



Also, you can check and edit it in the center line interface.



SingularPad User Guide


Coordinate element method

Coordinate element method can be used in the situation that the road is made up of lines and curves only.




SingularPad User Guide



You can check and edit it in the center line interface. You can design roads by importing files of road. There are abundant formats you can choose. Also, you can create a new one.



4.8.3 Vertical Profile



Vertical profile contains grade breaks, there are two methods, you can choose, enter the elevation data in each station and check.






4.8.4 Standard cross section

You can import cross section files. Each cross section has two parts, the left section and right section.





SingularPad User Guide

Usually we edit the left section first, enter parameters of width, slop and elevation data, and tap OK to save or tap next to enter the next one. The unit is meters




If the right section was same with left section, just tap the symmetry in the right section interface, it will get the right section automatically. If not, enter the right one.




SingularPad User Guide

If you need to enter ultra-height and ultra-width data, tap the cross section data you have already entered in the content list, and enter them.




4.8.6 Slope data

Enter cut or fill data of each station if you need.





4.9 Road stakeout

After design the road, click and stake it out in the roads database interface, it will auto add the start point of the road to the target stake point, follow the navigation information shown on the map.





When you get near the target point, the map will show a big circle as shown below, and when the accuracy is high enough to stake the point, SingularPad will alarm to let you know, then press  to finish this point stake, and in different situations you can choose different serial modes.





- Stake road by line: Default mode, when you get close to the road, it will guide you towards the road vertically. Just follow the row and stake it out.
- Stake road by point: Before your work, you need to enter the parameters to calculate the points you will stake next.

SingularPad User Guide




- Add peg: Calculate a point one time, enter the station and offset distance, enter positive distance, the point will be on the left side of the road. Enter negative distance, the point will be on the right side of the road.



Choose one point and follow the navigation information to stake it out,


- Recalculate: Calculate points with interval and offset distance, it will calculate points at one time according to the set parameters



Cross section measurement, auxiliary profile stakeout and stake road by cross section are similar to this mode, set parameters and stake them out.


4.10 Points database

The points, which are surveyed, staked, added, imported, and input from display map, will be stored in point database. The surveyed points will be shown under one base while surveying. Also, no matter where you need to select a point, all the points of the database are available.



- Add: Supports to add Input Point, and Display type Supports Local coordinate and geodetic coordinate
- Recover: After delete the points, you can recover them in deleted points interface
- Import: Import points by different formats of files
- Export: Export points by different formats of files
- Search: Enter the name of the point you want to inspect and show it out
- Share/Delete: Long press to choose the point you want share or delete

Tap a point to check the information about the base coordinate. The information includes antenna height, solution status, WGS84 Coordinate, local grid coordinate, base id and measure time. if you had calibrated the point, it will display offset parameters.



- Photo And Sketch: add notes by note, arrow, drawing and photo


4.11 Data export/import

SingularPad supports to import/export data including grid coordinate, Lat/Lon coordinate with various data format, support import dat/csv/kml file and export result of DXF/KML/shp/xls/csv.

4.11.1 Import points data


Tap Import data in project interface, there are some predefined data formats, click More to get more predefined formats.

SingularPad User Guide



- Data Type: support point database, line data base, transformation parameters file and code library
- Import File Format: support *.csv, *.dat, *.txt, *.kml format etc.
- Distance Unit: support meter, US survey feet and international feet

Besides, you can click new to create a User defined type.




SingularPad User Guide

- Format name: Enter the name for the format
- Extension name: support *.csv, *.dat, *.txt, *.xls,*.xlsx format
- Delimiter: support comma (,), semicolon (;), space (), tab (Tab)


Click to choose elements in the options list. Click backspace to eliminate the previous element selected. The elements include: code, name, northing, easting, elevation, latitude, longitude, altitude.

Choose one format to import data. The default export path is internal storage/ SingularPad / import. You can also change to any other path where the file is. Click preview to take an inspection whether the format is right.



4.11.2 Export points data

Tap Export in Project interface to export simple data of survey points. Also, click More formats to export the survey points with detailed information or other formats like stake points/lines, DXF, SHP, KML, RAW, RW5, HTML, CASS feature result.





- Export Path: the default export path is internal storage/ SingularPad/export; you can also change to any other path where the file is.
- File Name: support project name, operator, date, data time
- Export File Format: support *.csv, *.dat, *.txt, *.kml format etc.
- Distance Unit: support meter, US survey feet and international feet
- Distance Unit: open to export road section data

SingularPad User Guide

Besides, you can click New to create a user defined type. The elements include: id, name, code, latitude, longitude, altitude, northing, easting, elevation, N, E, Z, type, local time, UTC time, solution status, AGE, max delay, min delay, used satellites, tracked satellites, cut-off angle, mount point, measurement method, repeat, start data, end time, RMS, HRMS, VRMS, PDOP, VDOP, speed, heading, antenna type, measuring type, measuring height, antenna height, base id, base latitude, base longitude, base altitude, distance to ref, original latitude, original longitude, original altitude, undulation height, station correction x, station correction y, station correction h, inclination correction, pitch, roll, yaw, inclined angle, projected angle, stakeout type, target, station, offset, north diff, east diff, elevation diff.

For the points, lines and polygons you surveyed in point survey, you can export dxf file, then you can edit them in third party CAD software, or import to basemap to check, or import to CAD to stake. Choose the data that you want to export including survey point, input point, control point, stake point, base, line and polygon, and the layer properties includes name, code and height.




5 Total Station

SingularPad also can work with our TS1000 total station, and realize point survey, stakeout, CAD, etc.



5.1 Connect to total station

Click Connection. You can connect TS1000 total station to SingularPad. Choose device type as total station, and enable Bluetooth of TS1000 and connect.




After connecting TS1000, you can see the parameters showing in the window, VA (vertical angle) and HA (horizontal angle).

5.2 Set station

There are two methods you can set the station: Set station & orientation and free set station.

5.2.1 Set station & orientation

After you set up your total station at a control point, and you have a point or azimuth that you can set backsight, you can choose this mode.




- Occupancy Pt: Click to add or import the control coordinate
- Instrument height: the height from the measuring mark to the ground
- Set backsight: choose point or azimuth as backsight
- Backsight Pt: Click to add or import the control coordinate. If you choose azimuth as backsight, here need to enter Azimuth
- Observe: calculate the result, azimuth diff and distance diff

After enter all the parameters, Stand the prism at the backsight point, and the total station points the prism and clicks to observe. It will calculate the result, and apply it.

5.2.2 Free set station

If you want to set up TS1000 in the place without coordinate. You need to set up the total station to a place where the known points can be seen, input the coordinates of the known points, and then measure the known points, and finally calculate the coordinates of the erection points of the total station. The greater the number of known points, the higher the

accuracy.



- Instrument height: the height of TS1000, from the measuring mark to the ground
- Reflector: it includes 3 modes - prism, sheet and reflectorless
- Ranging mode: click  to choose ranging mode, precision measurement, fast measurement or tracking measurement.
- Add or Button Library: you can import through clicking buttons to enter or choose the coordinates of known points
- Calculate: after measured all the known points, click Calculate to get the coordinate of your current position.

5.3 Total station survey


After set station, you can start work in Survey interface, including all kind of survey and stakeout.

5.3.1 Point survey

Use total station to measure points. In the Survey interface, click Point Survey-> enter point name, code and reflector mode

SingularPad User Guide


Click  to start or stop collecting data, click  to record coordinates in controller.



- Suspension window: When not measured, the data is empty, and the coordinates and related information will be displayed after measurement
- Click  to choose ranging mode, precision measurement, fast measurement or tracking measurement.
- Click , it will auto jump map center.
- Click  to show the layers or calibration: google map/open street map/map calibration
- Click  to show the whole points on the interface.
- Click  to check point coordinates, you can add, recover, import, and export the data.
After you choose a point, you can check the details and take notes or photos
- Click  to set settings, display info and tool bar, in setting interface, you can choose the mode of point; in display info interface, you can add information to floating window you want below the interface; in tool bar interface, you can add or delete options to point survey interface. You can customize the interface to meet whatever layout needs you might have.
- Click  to connect dots into different shapes, line, polyline, polygon, arc, square, circle, etc.

5.3.2 Tps survey

Tps survey is similar with point survey, but shows more information of the point (vertical angle), HA (horizontal angle), SD (slope distance), HD (horizontal distance), VD (vertical distance)



Before survey, enter point name, code and choose reflector mode, then click  to start or

stop collecting data, click  to record coordinates in controller.



- Click  to set settings, display info and tool bar, in setting interface, you can choose the mode of point.
- Click  to check point coordinates, you can add, recover, import, and export the data.
After you choose a point, you can check the details and take notes or photos
- Click  to choose ranging mode, precision measurement, fast measurement or tracking measurement

5.3.3 Point stakeout



Go into Stake point interface, add or import the point coordinates you need to stakeout, of course you can choose from the button library.

SingularPad User Guide

- Click Add to input coordinates.



- Click button library to choose one.
- Click Import to get coordinates with different kinds of files; you can also define a new form.





SingularPad User Guide



When you choose a point to stake, SingularPad provides a navigation information, target distance and azimuth diff. According to the azimuth, adjust your total station and make it about $0^{\circ}0'0''$.

Then have your colleague walk to the line between the total station and the target point

with the prism, and click  to measure it. The hover window will then show you the distance forward or backward, guiding you to move the prism until you get it.



- Click  to create a QR code, if your colleague scanning this code with SingularPad, he can see the navigation information in real-time.





SingularPad User Guide

- Click  to choose ranging mode, precision measurement, fast measurement or tracking measurement.
- Click  to show the layers or calibration: google map/open street map/map calibration
- Click  to show the whole points on the interface.
- Click  to scale automatically
- Click , it will auto jump map center.
- Click  to set stakeout settings, display info and tool bar, you can edit the prompt range and range error
- Click , jump to lasted point
- Click , jump to next point
- Click , jump to previous point

5.3.4 CAD mapping

CAD mapping and CAD stakeout are similar, both are based on CAD file to realize. CAD mapping is mainly used for drawing, CAD stakeout is aimed to stakeout all the things in CAD files.



- Click  to build or import a new CAD file, supporting *.dxf, *.dwg format, Input parameters and save it.



SingularPad User Guide

Find the file you want to stake and import it. After create or import one, you can scan and edit it in the CAD layer.




- Click  to draw features. there are 12 types and methods you can choose, follow the prompts and draw. Click  to delete the thing you are drawing, click  to delete the last point, click  to finish it.




- Click  to choose ranging mode, precision measurement, fast measurement or tracking measurement.
- Click  to select a point anywhere you want to know the coordinate
- Click  to show the whole points on the interface.
- Click  , it will auto jump map center.
- Click  to show or hide the measure information and measure button.
- Click  to find tools; they can help you to work smoothly. For example, to find the intersection points of neighboring circles.
- Click  to set CAD settings, display info and tool bar, you can edit the prompt range and range error

SingularPad User Guide

In the CAD interface, you can choose a feature you want to stake, it will show up in blue. You can know the details about it, including length, start point, end point and center point. And choose the way to stake.



- Start station: If you set the start station as 5m, then final mileage will plus 5m.
 - Offset dist: If you set the offset 5m, then you will stake the line 5m away from the line you choose. Plus and minus represent different sides of the line.
 - Setting out by pile by coordinate: including station number, station distance, segment and key node.
- ① Station distance: Stake the line at a specified distance, for example, if the line is 40m, you set the specified distance as 8m. Then you will stake the line at 8m distance every segment
 - ② Segment: For example, if you set the line segment as 4, then you will stake the line at 4 segments, every segment length is the same.
 - ③ Station number: You will stake the line at the station at each interval point You can stake it out according to the direction.
 - ④ key node: It will stakeout the line with starting point, ending point, midpoint, fold point, etc.



Finally, according to the detailed points, you can stake the line out.


5.3.5 CAD stakeout

CAD stakeout is similar with CAD mapping.


SingularPad User Guide

- Click  to open a new CAD file, supporting *.dxf, *.dwg format, input parameters and save it
- Click  to manage each layer
- Click  to choose ranging mode, precision measurement, fast measurement or tracking measurement.
- Click  to set CAD background color, white, gray or black
- Click  to select a point anywhere you want to know the coordinate
- Click  to show the whole points on the interface.
- Click , it will auto jump map center.
- Click  to set CAD settings, display info and tool bar, you can edit the prompt range and range error
- Click  to check point coordinates, you can add, recover, import, and export the data.

After you choose a point, you can check the details and take notes or photos.



Also, you can choose a feature you want to stake, it will show up in blue. You can know the details about it, including length, start point, end point and center point. And choose the way to stake.




- Click  to create a QR code, if your colleague scanning this code with SingularPad, he can see the navigation information in time.
- Click , jump to lasted point
- Click , jump to next point
- Click , jump to previous point
- Click  to set stakeout settings, display info and tool bar, you can edit the prompt range and range error.

5.3.6 Line stakeout


Go into Stake line interface, add or import lines you need to stakeout.

- Click Add to input line parameters, there are two types you can choose



SingularPad User Guide



- Click Import to get coordinates with different kinds of files; you can also define a new format.



Choose a line to stake, set calculation mode and interval.




- Click  , jump to next line
- Click  , jump to previous line
- Click  to add stake

5.3.7 DSM stakeout


You can stake the elevation using the design surface, if you don't open a surface before, then you need to add one by adding, importing coordinates or choosing from the button library.

SingularPad User Guide

You can get a preview map after adding points and don't forget save it.




At the content list interface, you can find the surfaces you made, and you can edit, share and stake them.



SingularPad User Guide

If the current position is not within the range of the design surface, it will show “Out of Surface!” if the current position is within the range of the design surface, it will show the fill or excavation value.




6 Frequently asked functions

This chapter will show some frequently used functions, including device Information, localization, calibrate point

6.1 Device information

Go device information, click to check hardware version, firmware version, current data link, battery power and any other information of the device after connecting Bluetooth.





6.2 Location


Location is commonly needed once in one project, and all the points will be collected based on calibrated datum system.

Enter at least three groups' point to compute (for example, take K1, K2, K3 as known points, take A1, A2, A3 as measured points). After click calculate, the software will calibrate automatically.

SingularPad User Guide



- Add: Enter the coordinates of corresponding known point and GNSS point
- Import/Export: Support *.loc format
- Calculate: Calculate conversion parameters
- Name: Enter name
- Use horizontal/vertical control: Open to calculate the parameters to convert





After calculation, you can inspect the details in result interface, including conversion residual (($H. \leq 0.02$, and $V \leq 0.05$), ellipsoid parameter, projections parameter, horizontal adjustment and vertical adjustment parameter. Click Apply to confirm to replace datum.

6.3 Calibrate point

Calibrate Point function is applied when you need to change the position of Base station in the same project.

Click Calibrate Point in project interface, add known point coordinate, and measure GNSS point coordinate. The software will calibrate automatically. Apply to complete grid shift, all rover points will upgrade the coordinate.



- Click  to choose a point from database map
- Click  to start or stop collecting data
- Click  to choose a point from points database
- Click  to edit the coordinate
- Click Clear to delete conversion parameters

After calculate the offset of north, east and height in the base detail from Element will be changed, you can also clear offset to zero, which will cancel the grid shift setting.


6.4 Code library manager

This is a function for adding or managing the code. You can add the code for point, line and polygon by grouping. After add a code list what you need, it will be convenient to use point survey and stakeout. In addition, the description of code is good for you to survey features. In some situation, code will be easy, so you can select the description to know what you are surveying.


If you don't have a code list, you can modify current code list and add the code, if you add a

SingularPad User Guide

code list before, you can choose this code list when you create a new project.



- Click  to create or import a new code
- New: edit a new code
- Import: support *.cbd, *.csv, *.dat, *.txt formats



Input group name and code for layers, open auto connect by code, and choose data type and color, supporting line and polyline, you can scan the code you have created in edit interface, don't forget apply it.

Tips:

1. When you add a code library in the point interface, it will not apply in line or polygon interface.
2. You can enter a new code in the Survey and Stake surface, when you survey the point, the code will be stored in the current code list.

7 About Software

There is activation id, expiry date, the current version, company contact number, company official website.

Check whether there is an update, click "check lasted version" to download the latest version for installation when there is an update. If your software was not registered, call the salesman and get activation code, click software activation and enter it.

If you have some suggestions or advice, give us the feedback.



If you have any question and cannot find the answer in this manual, please contact us from SingularXYZ Website: www.singularxyz.com

Technical support email: support@singularxyz.com

Your feedback about this manual will help us improve it with future revisions.